


**WSS2012**  
**Wood Saving Stove**  
 saves about 70%  
 of firewood



## Directions for use:

- Remove ashes before starting a fire.
- Light dry sticks or chipped wood.
- When the fire is burning, put on the stove plate with the draw-tube.
- Adjust the efficiency sheet to the size of the pot and put it on.
- Insert the pot.
- **Always use the lid!**
- Place the wood feeding system.
- The flame is regulated by the wood supply.
- The air supply and thus the intensity of the flame can be regulated at the ventilation duct.



- The WSS is configured for pot sizes up to Ø 36 cm.
- Pans have to be put *directly on the stove plate without the efficiency sheet*. Three metal bars prevent the pan from falling off the stove.
- To use the residual energy of the embers take off the stove plate and put on the matching pot.
- **Caution: HOT! Use oven cloth!**
- When using other pots and pans take off the furnace shell and put them on top of the firing chamber.
- **Caution: HOT! Use oven cloth!**