



Operation instructions & Safety rules




1
Find a sunny place for your solar cooker.





2
Ensure the ground is level when operating your solar cooker.




3
Protect from strong winds.




4
Always use a pot that fits properly. Do not cook with an ill-fitting pot. Avoid burns from a hot pot. Remember that the lid is also heated up. Don't leave anything on it.




5
With a grate you can also use smaller pots.




6
Swing the reflector dish out of direct sun, step up from behind and you can safely and comfortably handle the pot.



7
Do not look into the reflector dish in full sun. For additional safety wear sun glasses.




8
The solar cooker needs realignment to the sun every 15 to 20 minutes. The cooker is correctly positioned when the shadow of the pin has completely disappeared. It is held in position by the cord.



9
For yourself, find a comfortable place in the shadow to watch the cooking process and the pin.

Once boiling the usage of a "haybox" is recommended as a safe and easy cooking method for meals that require long simmering. In this way meals can also be kept hot for consumption after the sun has set.



10
Use only soap and a soft cloth for cleaning the reflector. Cooking power will be lost by scratching the surface.



11
When not in use, swing the reflector dish upside down to protect it from rain.

The cooker can be left outside under normal weather conditions. In case of storm place the reflector dish face downwards on the ground. Never lean on a burnable wall in upright position!